



# Sol 3' Bed

SEC/AY/10/17/LT1  
51793 (LT)



## **IMPORTANT** **PLEASE READ BEFORE YOU CONTINUE FURTHER** **CARE AND MAINTENANCE**

- After unpacking this product please keep the original packaging in case it needs to be returned for any reason.
- Please ensure all fittings and parts are present before commencing with assembly.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- We strongly recommend that you keep children away from your work area.
- Assemble this product as close to its final position as possible.
- Never drag or push products as this could cause damage to the joints making it inferior.
- Do not drag or push items across your furniture as this may cause the surface to scratch.
- Do not place this product next to a radiator or in direct sunlight.
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- Do not place on a wet or damp floor as staining may occur to your floor.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.











\* Use of power tools to assemble this product will invalidate any claim and could damage this product making it unsafe!!!  
\* Please assemble on a clean soft surface to avoid damage.


\* Please check contents and read the instructions before commencing assembly.  
\* Assemble this product following the enclosed instructions carefully.  
\* Please take care to avoid damaging parts during assembly.



PARTS LIST

NUMBER	DESCRIPTION	QUANTITY	NUMBER	DESCRIPTION	QUANTITY
01	Headboard RightPost	01	06	FootboardCrossbeam	01
02	Headboard LeftPost	01	07	HeadboardCrossbeam	01
03	Footboard RightPost	01	08	Headboard Panel	01
04	Footboard LeftPost	01	09	Slat	12
05	Side Rail	02			

FITTINGS



A	 Ø1/4" x 110	08	E	 ALLEN KEY	01
B		08	F	 SPACER (WOODEN)	02
C	 Ø3,5 x 30	24	G	 Ø7 x 100	08
D	 Ø10 x 50	12	H	 Ø12 x 40	04




C	 Ø3,5 x 30	24
F	 SPACER (WOODEN)	02

\* Please fix the first slats adjacent to the headboard and footboard and work towards the middle of the bed using the spacer (F) as shown to ensure correct spacing. Fix all the slats to one siderail first then push the siderail tight against the slats and fix. Please, retain the allen key (E) and use periodically to check that all bolts are tight.


01






02



G		08
E		01



A	 Ø1/4" x 110	08
B		08
E	 ALLEN KEY	01