
51037(MY)

Corona 4 Door Wardrobe ASSEMBLY INSTRUCTIONS




IMPORTANTFOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- We strongly recommend that you keep children away from your work area.
- Assemble this product as close to its final position as possible.
- Never drag or push products as this could cause damage to the joints making it inferior.
- Do not place this product next to a radiator or in direct sunlight.
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur
- For general cleaning use a duster, and do not use detergents of any kind. However, the surface will need to be retreated from time to time. This can be done by using block wax (unperfumed) and rubbing it over the whole item.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.



- any claim and damage this product making it unsafe!!!

 * Please assemble on a clean soft surface to avoid damage.

Parts List

1	Top Panel	01	12
2	Right Side Panel	01	13
3	Left Side Panel	01	14
4	Base	01	15
5	Right Centre Panel	01	16
6	Large Fixed Shelf	01	17
7	Left Front Upright	01	18
8	Right Front Upright	01	19
9	Centre Front Upright	01	20
10	Top Back Plinth	01	21
11	Top Middle Plinth	01	22

12	Support Hanger	04
13	Long Hanger	01
14	Door Strip	02
15	Top Side Plinth	02
16	Left Centre Panel	01
17	Small Back Panel	02
18	Large Back Panel	01
19	Back Strip (Bottom)	01
20	Back Strip (Upper)	01
21	Adjustable Shelf	03
22	Left Door	01

23	Left Centre Door	01
24	Right Door	01
25	Centre Foot	01
26	Bottom Front Plinth	01
27	Bottom Side Plinth	02
28	Top Front Plinth	01
29	Back Panel	01
30	Small fixed Shelf	01
31	Short Hanger	01
32	Right Centre Door	01
33	Support block	02


Fittings


Α		36
В	Ø8x30	50
С	⊕ [□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	24
D	10x10	70
Е	③ [104


F		80
G		08
Н	(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	12
I	Black	04


J		12
K		06
L		13
М	Ø8x40	02


N		02
0		12
Р	1x 0 2x	01
		GE 2


























WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

P- HARDWARE LIST



(1x)

(<u>Innunus (I</u>

Wood Screw (Anti-Tip Kit) 3,5 x 25mm (1x)

(a) Washer (Anti-Tip Kit)

