
#### **DELTA SMALL TV UNIT ASSEMBLY INSTRUCTIONS**

Thank you for purchasing the **SMALL TV UNIT**. Please read the instructions carefully to ensure safe operation of the product.



Size: (W)890 x (D)390 x (H)490mm Colour: White / L.Grey / Taupe / D.Grey

PLEASE READ this sheet prior to assembly to familiarise yourself with the various stages of construction.

Carefully open the pack supplied and check the contents against the parts and fittings check list. Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.

**CAUTION**: There are small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit to avoid the danger of choking hazards.

# Tools Required Person Required Approximate Assembly Time x 2 1<sub>1/2</sub> Hour

Batch No : V2 10/20 Page 1 of 14

# IMPORTANT - READ CAREFULLY - RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

#### **INFORMATION**

- This product is intended for a maximum weight of **25kgs** and drawer load capacity **5kg** each. Do not exceed this weight.
- Due to the size of this product we recommend that is assembled in the room intended for use.
- When you ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly
- Unwrap all packaging materials and place the components on top of the carton box or not on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled as illustrated before use.
- Check all screws or bolts are tightened and inspect regularly.
- This product should only be used on firm, level ground.
- Keep small parts out of reach of children.
- Make sure the legs remain in contact with the ground.
- Tools not included.

#### **WARNINGS**

- DO NOT use power tools to construct this product.
- DO NOT over tighten screw or bolts.
- DO NOT use this product if parts are missing, damage or worn.
- DO NOT stand or sit on this product.

#### **CARE INFORMATION**

- Never use scourers, abrasives or chemical cleaners.
- To clean wipe with a sponge and soapy water. Do not use solvent based cleaners or detergents as they can bleach or damage the product.


Page **2 of 14** V2 10/20

Please check the pack contents before assembling the product. If any components are missing, please contact your retailer. The fittings pack contains small items that should be kept away from small children.


#### **Parts**

CODE	PART NAME		QTY
1	CENTER PANEL	15 x 390 x 340mm	1
2	SIDE PANEL (R)	15 x 390 x 340mm	1
3	SIDE PANEL (L)	15 x 390 x 340mm	1
4	FIX PANEL	15 x 369 x 480mm	1
5	CENTER PANEL	15 x 368 x 162.5mm	1
6	TOP PANEL	15 x 390 x 890mm	1
7	DRAWER SIDE (L)	15 x 115 x 330mm	2
8	DRAWER SIDE (R)	15 x 115 x 330mm	2
9	DRAWER BACK PANEL	15 x 115 x 177mm	2
10	DRAWER FRONT (L)	15 x 158 x 227mm	1


CODE	PART NAME		QTY
11	DRAWER FRONT (R)	15 x 158 x 227mm	1
12	BOTTOM PANEL	15 x 390 x 890mm	1
13	BACK PANEL	2.5 x 372 x 349mm	1
14	BACK PANEL	2.5 x 489 x 349mm	1
15	DOOR	15 x 355 x 332mm	1
16	DRAWER BOTTOM	2.5 x 322 x 185mm	2




Page **3 of 14** V2 10/20



## Fixings (not to scale)







# **Layout Parts on Soft Surface**


## STEP 1







Page **5 of 14** 













Page **8 of 14** 




## STEP 9










Page **10 of 14** 











## **Complete Assembly**

Your **DELTA SMALL TV UNIT** is now completely assembled

Periodically check to ensure that the components are in their proper position, free from damage. Also, make sure the connectors are tight and secure.



Keep instructions for future reference



Page **14** of **14** V2 10/20