

Assembly Instructions

Thank you for purchasing a **Birlea** product. For a chance to win a Love 2 Shop voucher simply post a picture of your new product on your preferred social channels tagging Birlea Furniture and using the hashtag **#ShareYourStyle** and **#Birlea**. One winner will be selected at random each month.

To view our full terms and conditions please visit www.birlea.com

Are you happy with your purchase?

Yes: That's great, we would love to hear more from you. Please leave us a review on our social media channels or Trustpilot. Your feedback will be greatly appreciated.

No: If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer you purchased the item from. We will work with the retailer to resolve your issue as quickly as possible.

() © G Y D Ø





ASSEMBLY INSTRUCTIONS HIGHGATE LARGE TV UNIT

IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR HIGHGATE LARGE TV UNIT.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

HEALTH & SAFETY:

DO NOT use this item if any parts are missing, damaged or worn.

DO NOT use this item unless all fixings are secured.

Please keep small parts out of reach of children.

Always use on a level, even surface.

It is recommended that two people handle and assemble the item.

Birlea advise you use the wall straps provided to further enhance the safety of this product.

CARE & MAINTENANCE:

Assemble in the room of use.

To avoid damages assemble the item on a soft, clean surface

Periodically check all screws & fixings to ensure they are secure.

DO NOT push the item as this will damage the base.

Always lift the item with two people to reposition.


Keep any sharp objects away from the item.


This product is manufactured in pine which is a wood with natural characteristics including knots, grains, clusters or indentations.


On unpacking the item you may notice an odour due to production processes but this will disappear after a period of time.

DO NOT place the item next to a radiator or direct sunlight - this item is susceptible to temperature change. It is recommended an even room temperature be maintained with no sudden fluctuations. DO NOT place hot or cold items directly onto the surface of the item as marking will occur

For general cleaning use a duster or damp cloth (almost dry) not wet - do not use soap and water, detergents, aerosol sprays or any polish as use of these materials would invalidate any claims. DO NOT place the item onto wet or damp flooring as staining may occur to the floor.








PARTS LIST

HARDWARE LIST: Carton 1 of 1


Carton 1 of 1:		Part	Description		Qty	
Part	Description	Qty	Α	CAM NUT 15mm		28
1	Top Panel	1	В	CAM BOLT	OTTENN	28
2	Bottom Panel	1	С	WOOD DOWEL M6 x 25mm		30
3	Left Divider Panel	1	D	PVC NAIL	Q	6
4	Right Divider Panel	1	E	CSK SCREW M4 x 45mm	Ounter	4
5	Shelf Panel	1	F	CSK SCREW M4 x 16mm	Sector	16
6	Left Panel	1	G	HINGES 7/8"	P	4
7	Right Panel	1	Н	T/MS SCREW M4 x 22mm	Ornan .	2
8	Plinth Panel	1	I	TXM NOSE ROUND HANDLE	\Diamond	2
9	Right Front & Left Back Post Panel	2	J	NAIL		35
10	Left Front & Right Back Post Panel	2				
11	Door	2	** You will need a screwdriver and a small mallet (NOT provided)			
12	Back Panel	1				



** WARNING: THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE. Page 2 of 8




Page 3 of 8






Attach the Left Divider Panel (3) and Right Divider Panel (4) to Bottom Panel (2) with Screw (E) by screwdriver (not provided).


DO NOT use any power tools as this may damage the frame and will invalidate any claim.







Attach the Right Front & Left Back Post Panel (9) and Left Front & Right Back Post Panel (10) to Left Panel (6) and Right Panel (7) by screwdriver (not provided). **DO NOT** use any power tools as this may damage the frame and will invalidate any claim.










Fix Hinges (G) onto Left Panel (6) and Right Panel (7) with Screw (F) by screwdriver (not provided).

Fix Handle (I) with Screw (H) as shown by screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.



.Additional Information:

.For complete product information, images and dimension diagrams please visit the website www.birlea.com

.If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.

.Why don't you send us photos of your assembled furniture to info@birlea.com to be shared in our #birleahome feature on lnstagram.