

ASSEMBLY INSTRUCTIONS

SANTIAGO 2 DOOR 1 SHELF FLAT SCREEN TV UNIT

IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR SANTIAGO 2 DOOR 1 SHELF FLAT SCREEN TV UNIT.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

HEALTH & SAFETY:

DO NOT use this item if any parts are missing, damaged or worn.

DO NOT use this item unless all fixings are secured.

Please keep small parts out of reach of children.

Always use on a level, even surface.

It is recommended that two people handle and assemble the item

CARE & MAINTENANCE:

Assemble in the room of use.

To avoid damages assemble the item on a soft, clean surface

Periodically check all screws & fixings to ensure they are secure.

DO NOT push the item as this will damage the base.

Always lift the item with two people to reposition.

Keep any sharp objects away from the item.

This product is manufactured in pine which is a wood with natural characteristics including knots, grains, clusters or indentations

On unpacking the item you may notice an odour due to production processes but this will disappear after a period of time.




DO NOT place the item next to a radiator or direct sunlight – this item is susceptible to temperature change.

It is recommended an even room temperature be maintained with no sudden fluctuations.


DO NOT place hot or cold items directly onto the surface of the item as marking will occur













For general cleaning use a duster or damp cloth (almost dry) not wet – do not use soap and water, detergents, aerosol sprays or any polish as use of these materials would invalidate any claims.


DO NOT place the item onto wet or damp flooring as staining may occur to the floor



www.birlea.com








Parts List			Hardware List		
Part	Description	Qty	Part	Description	Qty
1	Top Panel	1	A	Wooden Dowel 	16
2	Right Panel	1	B	14 mm Screw 	26
3	Right Centre Panel	1	C	35 mm Screw 	28
4	Left Centre Panel	1	D	40 mm Screw 	4
5	Left Panel	1	E	19 mm Bolt 	2
6	Base Panel	1	F	Handle 	2
7	Back Panel	1	G	Door Hinge 	4
8	Right Front Frame	1	H	Clip 	2
9	Front Frame	1	J	Plug 	2
10	Left Front Frame	1	K	Shelf Support 	4
11	Shelf Panel	1	L	Corner Bracket 	1
12	Door	2	M	Tack 	26
13	Cleat	4	** You will need a small mallet and a screwdriver.		




Step 1: Insert the right panel (2) to the right front frame (8) making sure the parts are fully pushed together and lined up. Place the cleats (13) between the marks shown and secure using hardware part C and a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim




Step 2: Insert the left panel (5) to the left front frame (10) making sure the parts are fully pushed together and lined up. Place the cleats (13) between the marks shown and secure using hardware part C and a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim




Step 3: Insert hardware parts A and K using a small mallet (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim




Step 4: Attach the right centre panel (3) and left centre panel (4) to the base panel (6) using hardware part D and a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim




Step 5: Attach the left panel (5) and front frame (9) using hardware part C using a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim




Step 6: Attach the right panel (2) using hardware part C. Attach hardware part L using hardware part B. You will need to use a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim





Step 7: Attach the top panel (1) using hardware part C and a screwdriver (not provided).


DO NOT use any power tools as this may damage the frame and will invalidate any claim



Step 8: Attach the back panel (7) using hardware part M and a small mallet (not provided).
DO NOT use any power tools as this may damage the frame and will invalidate any claim




Step 9: Insert the shelf panel (11).
DO NOT use any power tools as this may damage the frame and will invalidate any claim




Step 10: Attach hardware part G to the doors (12) using hardware part B, then attach hardware part F using hardware part E. You will need to use a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim




Step 11: Attach the doors (12) using hardware part B and a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim



Step 12: Attach hardware parts H to the base panel (6) using hardware part B. Insert hardware part J to hardware part H then push the doors shut to mark the wood. Secure hardware part J to the doors (12) using hardware part B. You will need to use a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim



Additional Information:

- For complete product information, images and dimension diagrams please visit the website www.birlea.com
- If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- Why don't you send us photos of your assembled furniture to info@birlea.com to be shared in our #birleahome feature on Instagram.