

Assembly Instructions

Thank you for purchasing a Birlea product.


For a chance to win a *Love 2 Shop* voucher simply post a picture of your new product on your preferred social channels tagging Birlea Furniture and using the hashtag **#ShareYourStyle** and **#Birlea**. One winner will be selected at random each month.

To view our full terms and conditions please visit our website. www.birlea.com

Are you happy with your purchase?

- *Yes:* That's great, we would love to hear more from you. Please leave us a review on our social media channels or Trustpilot. Your feedback will be greatly appreciated.
- *No:* If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer you purchased the item from. We will work with the retailer to resolve your issue as quickly as possible.







ASSEMBLY INSTRUCTION

BEDSIDE TABLE

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Assembly to be carried out by a competent adult only.

During assembly children should be kept away from the product due to the possible risk of injury.

Do not use the furniture if any part is broken, torn or missing and use only spare parts approved by the manufacturer.

Assemble the furniture on a soft level surface to avoid damaging the product or your floor.

We recommend furniture be assembled near where they will be placed, to avoid moving the product unnecessarily once assembled.

If there is a need to move the furniture, please remove all loose items and have extra hands to help lift the furniture to the desired location. Dragging the furniture will damage both the furniture and the floor.

Ensure that fingers and legs are clear of all adjustments when adjusting this product.

Regularly check and re-tighten (if necessary) all bolts on furniture that you have assembled yourself.

This product is suitable for children in the age range 5-12 years.


Care and Maintenance of your Furniture

Avoid placing hot items directly onto the surface unless using a thick insulation material such as placemats or coasters. Heat may lead to discolouration or other damage to the surface of the product.

Use a soft cloth that has been dampened in water to clean the surface of this product. Do not use abrasive cleaners. furniture wax or polish on the surface of this product, as it may damage the surface.

CAUTION: FREQUENT EXPOSURE TO DIRECT SUNLIGHT OR SIMILAR SOURCES MAY CAUSE THE SURFACE TO DISCOLOUR OR FADE.






Parts List											
PART	DESCIRPTION	QTY	BOX	PART	DESCIRPTION	QTY	BOX				
1	Right Side Panel	1	1	6	Drawer Back	1	1				
2	Top Panel	1	1	7	Drawer Right	1	1				
3	Bottom Panel	1	1	8	Drawer Front	1	1				
4	Back Panel	1	1	9	Drawer Bottom	1	1				
5	Drawer Left	1	1	10	Left Side Panel	1	1				

HARDWARE (IN BOX 1)


Α		Ø15x12mm	8	Е	BURNOUTH	M4x25mm	5
В	82 M	M6x38mm	12	F	OP		1
С		M6x25mm	8	G		55x16mm	1
D		Ø12x10mm	4	Н	Milit	M4x14mm	1

**You will need a Phillips head screwdriver and a Flat head screwdriver (not provided).


























Additional Information:

- For complete product information, images and dimension diagrams please visit the website www.birlea.com
- If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- Why don't you send us photos of your assembled furniture to <u>info@birlea.com</u> to be shared in our #birleahome feature on Instagram.

