
WHITE/NATURAL WAX PANAMA FLAT SCREEN TV UNIT ASSEMBLY INSTRUCTIONS




IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.




TOOLS REQUIRED

PARTS LIST

<u>Please Note:</u>
The below parts have all been stamped with the part number to help identify them during assembly.

Part Number	Part Code	Part Description	Quantity	<u>Carton</u>
1	S300-305-053-MY1-01	Right Side Panel	1	1/1
2	S300-305-053-MY1-02	Left Side Panel	1	1/1
3	S300-305-053-MY1-03	Right Front Upright	1	1/1
4	S300-305-053-MY1-04	Left Front Upright	1	1/1
5	S300-305-053-MY1-05	Top Panel	1	1/1
6	S300-305-053-MY1-06	Shelf	1	1/1
7	S300-305-053-MY1-07	Front Crossbeam	1	1/1
8	S300-305-053-MY1-08	Base	1	1/1
9	S300-305-053-MY1-09	Back Side Panel	2	1/1
10	S300-305-053-MY1-10	Back Centre Panel	1	1/1
11	S300-305-053-MY1-11	Right Division Panel	1	1/1
12	S300-305-053-MY1-12	Left Division Panel	1	1/1
13	S300-305-053-MY1-13	Door	2	1/1

FITTINGS LIST




PARTS REQUIRED


1 - RIGHT SIDE PANEL x1
2 - LEFT SIDE PANEL x1

HARDWARE REQUIRED



TOOLS REQUIRED





STEP 2

PARTS REQUIRED

1 - RIGHT SIDE PANEL x1


2 - LEFT SIDE PANEL x1


3 - RIGHT FRONT UPRIGHT x1

4 - LEFT FRONT UPRIGHT x1

HARDWARE REQUIRED











PARTS REQUIRED


1 - RIGHT SIDE PANEL x1
2 - LEFT SIDE PANEL x1

HARDWARE REQUIRED



TOOLS REQUIRED






STEP 4


PARTS REQUIRED

7 - FRONT CROSSBEAM x1
8 - BASE x1

HARDWARE REQUIRED










PARTS REQUIRED




HARDWARE REQUIRED




TOOLS REQUIRED






STEP 6


PARTS REQUIRED





HARDWARE REQUIRED













PARTS REQUIRED


11 - RIGHT DIVISION PANEL x1


12 - LEFT DIVISION PANEL x1


HARDWARE REQUIRED














PARTS REQUIRED




HARDWARE REQUIRED










J

G




STEP 12


PARTS REQUIRED

13 - DOOR x2

HARDWARE REQUIRED








PARTS REQUIRED








HARDWARE REQUIRED


E	M4 x 22mm	02
F	©	02

TOOLS REQUIRED









ADJUSTMENTS

