


# ROWAN TV UNIT ASSEMBLY INSTRUCTIONS

Thank you for purchasing the ROWAN TV UNIT

Please read the instructions carefully to ensure safe operation of this product.



Size:39x150x32.5cm

---



**PLEASE READ** this sheet prior to assembly to familiarise yourself with the various stages of construction.

Carefully open the pack supplied and check the contents against the parts and fittings check list. Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.

**CAUTION:** There are small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit to avoid the danger of choking.

---

## Tools Required



Number of people



2 Hour  
Set Up

# ROWAN TV UNIT ASSEMBLY INSTRUCTIONS

## **IMPORTANT - READ CAREFULLY - RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

### **INFORMATION**

- This product is designed to hold 30Kg spread evenly over the whole unit.
- Do not exceed this weight.
- We recommend that this unit is assembled in the room intended for use.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent any accidental scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled as illustrated before use.
- Check all screws or bolts are tightened and inspect regularly
- Tools not included unless specified in parts list.

### **WARNINGS**

- This product should only be used on a firm and level floor.
- Keep small parts out of reach of children.
- Make sure the legs remain in contact with the floor.
- DO NOT use power tools to construct this product.
- DO NOT tighten screws until all parts are assembled or as advised in this guide.
- DO NOT over-tighten screws or bolts.
- DO NOT use this product if parts are missing, damaged or worn.
- DO NOT sit or stand on the product.
- DO NOT place hot or Warm objects on the surface as these may damage the Product .  
Always use a suitable heat resistant mat.


### **CARE INFORMATION**

- Never use scourers, abrasives or chemical cleaners.
- To clean, wipe with a damp sponge and warm soapy water.
- Do not use solvent based cleaners or detergents as they can bleach or damage the product.


## Parts and Fittings Checklist

Please check the pack contents before assembling the product. If any components are missing, please contact your retailer.

The fittings pack contains small items that should be kept away from children.



## General Hints & Tips



# ROWAN TV UNIT ASSEMBLY INSTRUCTIONS


All parts are packed in one carton

1	2	3
Description: MIDDLE PANEL-LEFT Qty: 1 Size: 340x275x15mm Carton No: 1/1	Description: MIDDLE PANEL-RIGHT Qty: 1 Size: 340x275x15mm Carton No: 1/1	Description: SHELF Qty: 1 Size: 338x492x15mm Carton No: 1/1
4	5	6
Description: SIDE PANEL-LEFT Qty: 1 Size: 355x275x15mm Carton No: 1/1	Description: SIDE PANEL-RIGHT Qty: 1 Size: 355x275x15mm Carton No: 1/1	Description: BOTTOM PANEL Qty: 1 Size: 390x1500x15mm Carton No: 1/1
7	8	9
Description: BACK PANEL Qty: 1 Size: 283x1474x2.7mm Carton No: 1/1	Description: TOP PANEL Qty: 1 Size: 390x1500x15mm Carton No: 1/1	Description: DOOR Qty: 2 Size: 269x502x33mm Carton No: 1/1

# ROWAN TV UNIT ASSEMBLY INSTRUCTIONS

## Fittings (to scale)

Code	Item	Quantity
A	CAM BOLT (7x39mm )	8
B	CAM NUT	8
C	DOWEL (8x30mm )	20
D	SCREW (3.5x14mm)	20
E	SCREW (5x40mm)	12
F	SCREW (4x14mm)	20




## Fittings (not to scale)

Code	Item	Quantity
G	BACK PANEL SUPPORT	12
H	ADJUSTABLE PLASTIC GLIDE	2
I	METAL PLATE	4
J	LEG (Ø40xØ25x200mm)	4
K	LEG (Ø40xØ25x190mm)	2
L	HINGE	4
M	MAGNET SNAPPER	2


ROWAN TV UNIT ASSEMBLY INSTRUCTIONS

STEP 1


For this step:  
*Tools required*




*Fittings required*



C X4




E X4




STEP 2


For this step:  
*Tools required*




*Fittings required*



C X8




E X8




ROWAN TV UNIT ASSEMBLY INSTRUCTIONS

STEP 3



For this step:  
**Tools required**



**Fittings required**




F x20



I x4

STEP 4



For this step:  
**Tools required**



H x2




J x4



K x2


ROWAN TV UNIT ASSEMBLY INSTRUCTIONS

STEP 5




For this step:  
**Tools required**

**Fittings required**



C x8


STEP 6



For this step:  
**Tools required**




**Fittings required**



A x8






D x4






M x2




ROWAN TV UNIT ASSEMBLY INSTRUCTIONS

STEP 7	
	<p>For this step:</p> <p><b>Tools required</b></p>  <p><b>Fittings required</b></p>  <p>B x8</p>

STEP 8	
	<p>For this step:</p> <p><b>Tools required</b></p>  <p><b>Fittings required</b></p>  <p>G x12</p>

ROWAN TV UNIT ASSEMBLY INSTRUCTIONS

STEP 9



For this step:  
*Tools required*



*Fittings required*




D x8



L x4

STEP 10



For this step:  
*Tools required*









*Fittings required*



D x8

## STEP 11




# ROWAN TV UNIT ASSEMBLY INSTRUCTIONS

## Assembly Completed


Your ROWAN TV UNIT is now completely assembled.

Periodically check to ensure that the components are in their proper position, free from damage.

Also, make sure the connectors are tight and secure.



**Keep instructions for future reference**



**Supplied By**  
**GFW The Furniture Warehouse**  
**Waterside Distribution Centre**  
**Waterside Business Park**  
**Johnson Road**  
**Lancashire**  
**BB3 3RT**  
**[www.gfwlimited.co.uk](http://www.gfwlimited.co.uk)**