

# ASCH 15



Thank you for choosing this furniture.

**BEFORE YOU START ASSEMBLY** please store the carton at room temperature for 48 hours or more so the contents can acclimatise.

**PLEASE RETAIN ALL PACKING UNTIL YOU HAVE COMPLETED ASSEMBLY.**

## CARING FOR YOUR FURNITURE

Please avoid placing your chair close to radiators or other direct sources of heat.

This chair is not suitable for use in humid environments or outdoors.

It is best to avoid exposing your furniture to continued bright sunlight as it can affect the colour.

Any fluid spills should be removed as quickly as possible.

Always lift your chair when moving as dragging may cause damage to your furniture or flooring.

This chair is designed for domestic use only with a maximum loading of 110kg.


## AFTER CARE

Wipe the surfaces with a damp cloth. Please do not use detergents, bleach or chemicals on your furniture.

RETAIN THE ALLEN KEY PROVIDED TO TIGHTEN THE LEGS OCCASIONALLY. Do not stand or step on this chair.

**BUILD YOUR FURNITURE ON A SOFT CLEAN COVER TO AVOID COMPONENTS BEING MARKED OR DAMAGED DURING ASSEMBLY.**

## PARTS LIST



## BEFORE YOU START ASSEMBLY

Please check that you have all the correct parts and fittings as detailed in the Parts List above.

In the unlikely event that you require to order spare parts please refer to your delivery note for details of how to order on our Parts Website.

**[www.coreproducts.co.uk/parts](http://www.coreproducts.co.uk/parts)**


BATCH NUMBER

**BAZ7379**

**PLEASE RETAIN THIS INSTRUCTION LEAFLET AND ALLEN KEY FOR FUTURE USE.**


**ASSEMBLE YOUR CHAIRS ONE AT A TIME TO AVOID MIXING UP COMPONENTS.  
BUILD YOUR CHAIRS ON A CLEAN SURFACE TO AVOID COMPONENTS BEING MARKED DURING ASSEMBLY.**

01





Slot legs together ensuring the arrows on the legs are facing the correct way.

02




Loose fix centre bolt A

03 Arrows to face the front



**ARROWS TO FACE THE FRONT OF SEAT**  
Place the chair legs onto the upturned seat and loose fix

04



#### IMPORTANT

Using a tape measure check the leg positioning against these approximate sizes.

If the measurements are incorrect remove the bolts and swap the crossing point of the leg components around.

Failure to do this will affect the strength and stability of your chair.

Once this check is completed fully tighten all the bolts.

**RETAIN ALLEN KEY TO TIGHTEN BOLTS WHEN NECESSARY.**