


- A. Take the headboard (1) and slot in the back side panels (5). Do the same with the footboard (2) slot in the front side panels (4).
- B. Pull the front / back side panels (4 + 5) together, then insert the centre support (3) to the holes in the side on oneside, then repeat for the other side.
- C. Put slats (6) in place on the side panels (4 + 5).


3

PARTS LIST



1. Headboard
3. Centre Support
5. Back Side Panel
2. Footboard
4. Front Side Panel
6. Slat

2



The JUNIOR BED is now complete, please read the user guide notes to maintain the unit to its highest standard.

USER GUIDE

Thank you for choosing a KIDSAW product. Please take a little time to read the important safety notes detailed below. This will ensure many years of happy, safe use.

SAFETY WARNINGS

- WARNING** DO NOT PLACE THIS CHILD'S BED NEAR HEAT SOURCES, WINDOWS AND OTHER FURNITURE.
- WARNING** DO NOT USE THIS CHILD'S BED IF ANY PART IS BROKEN, TORN OR MISSING.

ADDITIONAL INFORMATION

- The racing car junior bed conforms to **BS 8509:2008+A1:2011**.
- The bed is intended for use by a child from the age of **18 months to 4 years old**.
- We recommend a cot mattress of dimensions **H.10 x W.70 x D.140cm** to be used with this bed.
- Periodically check the bed to make sure all fittings are tightened securely.
- Make sure the bed is not placed too close to **other furniture, windows, blind cords, curtain pulls or other strings and cords** due to children bouncing, jumping and climbing the bed. We recommend you place the bed tight to a wall or have **at least 300mm** between it and the bed.
- ONLY** use spares approved by Kidsaw Ltd.
- ONLY** adults should assemble this bed.

CARE & MAINTENANCE

- All surfaces should be wiped over using a damp cloth to clean.
- Never clean with abrasive, ammonia based, bleach or spirit type cleaner

4


**IMPORTANT
KEEP FOR FUTURE REFERENCE
& READ CAREFULLY**

RACING CAR JUNIOR BED

Follow us on
facebook



www.facebook.com/kidsaw



INSTRUCTIONS

KIDSAW[®]
MAKES FURNITURE CHILDS' PLAY

Kidsaw Ltd
Tel: +44 (0)116 2519551 Email: support@kidsaw.co.uk
www.kidsaw.co.uk