

Assembly Instructions

Thank you for purchasing a Birlea product.

For a chance to win a Love 2 Shop voucher simply post a picture of your new product on your preferred social channels tagging Birlea Furniture and using the hashtag #ShareYourStyle and #Birlea. One winner will be selected at random each month.

To view our full terms and conditions please visit www.birlea.com

Are you happy with your purchase?

Yes: That's great, we would love to hear more from you. Please leave us a review on our social media channels or Trustpilot. Your feedback will be greatly appreciated.

No: If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer you purchased the item from. We will work with the retailer to resolve your issue as quickly as possible.













ASSEMBLY INSTRUCTIONS

IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING THE BED.

IMPORTANT: - READ CAREFULLY - RETAIN FOR FUTURE REFERENCE

HEALTH & SAFETY:

DO NOT jump on this bed frame.

DO NOT use this bed frame if any parts are missing, damage or worn.

DO NOT use this bed frame unless all fixings are secured.

Please keep small parts out of reach of children.

Always use on a level, even surface.

This bed is tested to European safety standard BS EN 747-1 & 2:2012+4I:2015

WARNING: If this bed is placed on a non-carpeted floor you must place some protection under all legs to stop the bed frame from moving. If this is not adhered to there is no guarantee if the bed frame collapses.

WARNING: High beds are not suitable for use by children under six years of age due to risk of injury from falls

WARNING: Please note the area underneath the bed is to used for storage purpose only.

WARNING: High beds can present a serious risk of injury from strangulation if not used correctly. Never attach or hang anything on any part of the frame that is not designed to be used with the bed, for example, but not limited to ropes, strings, cords, hooks, belts, and bags.

WARNING: Do not use the high bed if any structural part is broken or missing.

WARNING: Children can become trapped between the bed and the wall, a roof pitch, the ceiling, adjoining pieces of furniture (e.g. cupboards) and the like. To avoid risk of serious injury, the distance between the top safety barrier and the adjoining structure shall not exceed 75mm or shall be more than 230mm.

- Always follow the manufacturer's instructions.
- Use ladder for entering and leaving upper bunk.

CARE & MAINTENANCE:

Assemble in the room of use.

Assemble on a soft, clean surface.

Please check regularly that all assembly fastening are properly tightened.

DO NOT push the bed frame as this will damage the legs.

Always lift the bed with two people to reposition.

Use a soft, dry cloth to clean - do not use any detergents or chemicals.

Avoid contact with water and direct sunlight. Do not place bed near heat sources, window to keep the humidity low and prevent mould in and around the bed

INFORMATION

- Maximum thickness of mattress 15cm. Please refer to marking headboard.
- Recommend size of mattress L192cm x W92cm x H15cm
- When you are ready to start, make sure that you have the right tools, plenty of space on a clean, dry area for assembly.
- Check the pack and make sure you have all the part listed.
- Ensure that this product is fully assembly and secured as illustrated before use.



Vendor: S000398

You
Tube

ASSEMBLY INSTRUCTIONS LEYTON CABIN BED

IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR LEYTON CABIN BED.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

HEALTH & SAFETY:

DO NOT use this item if any parts are missing, damaged or worn.

DO NOT use this item unless all fixings are secured.

Please keep small parts out of reach of children.

Always use on a level, even surface.

It is recommended that two people handle and assemble the item.

Birlea advise you use the wall straps provided to further enhance the safety of this product.

CARE & MAINTENANCE:

Assemble in the room of use.

To avoid damages assemble the item on a soft, clean surface

Periodically check all screws & fixings to ensure they are secure.

DO NOT push the item as this will damage the base.

Always lift the item with two people to reposition.

Keep any sharp objects away from the item.

This product is manufactured in pine which is a wood with natural characteristics including knots, grains, clusters or indentations.

On unpacking the item you may notice an odour due to production processes but this will disappear after a period of time.

DO NOT place the item next to a radiator or direct sunlight - this item is susceptible to temperature change. It is recommended an even room temperature be maintained with no sudden fluctuations.

DO NOT place hot or cold items directly onto the surface of the item as marking will occur


For general cleaning use a duster or damp cloth (almost dry) not wet - do not use soap and water, detergents, aerosol sprays or any polish as use of these materials would invalidate any claims.


DO NOT place the item onto wet or damp flooring as staining may occur to the floor.


INFORMATION:

Maximum thickness of mattress 15cm. Please refer to making headboard.

Recommend size of mattress L192cm x W92cm x H15cm.







PART LIST

1 of	3:
	1 of

Part	Description	Qty
7	Base Panel	2
8	Cabinet Top Panel	1
9	Cabinet Left Panel	1
10	Cabinet Right Panel	1
11	Cabinet Center Panel	1
12	Cabinet Bottom Panel	1
13	Cabinet Plinth Panel	1
14	Cabinet Movable Panel	1
15	Drawer Front Panel	2
16	Drawer Left Panel	2
17	Drawer Right Panel	2
18	Drawer Back Panel	2
19	Drawer Support Panel	2
21	Ladder Step Panel	2

Carton 2 of 3:

Part	Description	Qty
3	Back Panel	1
4	Front Panel	1
5	Support Panel	2
6	Bottom Back Panel	1

Hardware List

Carton 3 of 3:

Part	Description	Qty
1	Left Panel	1
2	Right Panel	1
7	Base Panel	4
20	Ladder Right Panel	1
22	Ladder Bottom Support Panel	2
23	Cabinet Back Panel	2
24	Drawer Bottom Panel	2

** You will need a screwdriver and a small mallet (NOT provided)

HARDWARE LIST

Carton 1 of 3:

Part Description Qty A CAM NUT 15mm 30 B CAM BOLT 30 C WOOD DOWEL M6 x 25mm 45 D STEEL NUT M6 36 E CSK SCREW M3.5 x 12mm 36 F CSK SCREW M4 x 30mm 14 G CSK SCREW M4 x 38mm 10 H JCN M6 10 I JCBC SCREW M6 x 12mm 4 J JCBC SCREW M6 x 25mm 3 K JCBC SCREW M6 x 30mm 7 L JCBC SCREW M6 x 50mm 13 M PVC NAIL 5/8" 3 N METAL RUNNER TRUCK 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT 4 T KNOB HANDLE 2613 2 U STICKER 20mm 18 V ALLEN KEY 2 W CSK SCREW M4 x 45mm 2	O G.	ton roro.		
B CAM BOLT C WOOD DOWEL M6 x 25mm D STEEL NUT M6 E CSK SCREW M3.5 x 12mm F CSK SCREW M4 x 30mm G CSK SCREW M4 x 38mm H JCN M6 I JCBC SCREW M6 x 12mm J JCBC SCREW M6 x 25mm K JCBC SCREW M6 x 30mm T L JCBC SCREW M6 x 30mm D T L JCBC SCREW M6 x 50mm M PVC NAIL 5/8" N METAL RUNNER TRUCK 14" Q NAIL R PVC L BRACKET S METAL SHELF SUPPORT T KNOB HANDLE 2613 V ALLEN KEY 2 30 45 45 10 12 13 14 15 16 17 18 18 19 19 10 10 10 10 10 10 10 10	Pa	t Description		Qty
C WOOD DOWEL M6 x 25mm 45 D STEEL NUT M6 31 E CSK SCREW M3.5 x 12mm 36 F CSK SCREW M4 x 30mm 14 G CSK SCREW M4 x 38mm 10 H JCN M6 30 10 I JCBC SCREW M6 x 12mm 4 J JCBC SCREW M6 x 25mm 3 K JCBC SCREW M6 x 30mm 7 L JCBC SCREW M6 x 50mm 31 M PVC NAIL 5/8" 3 N METAL RUNNER TRUCK 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT 4 T KNOB HANDLE 2613 2 U STICKER 20mm 18 V ALLEN KEY	Α	CAM NUT 15mm		30
D STEEL NUT M6 E CSK SCREW M3.5 x 12mm F CSK SCREW M4 x 30mm G CSK SCREW M4 x 38mm H JCN M6 I JCBC SCREW M6 x 12mm J JCBC SCREW M6 x 25mm K JCBC SCREW M6 x 30mm T L JCBC SCREW M6 x 30mm M PVC NAIL 5/8" N METAL RUNNER TRUCK 14" Q NAIL R PVC L BRACKET S METAL SHELF SUPPORT T KNOB HANDLE 2613 V ALLEN KEY 2 set 3 13 13 14 15 10 10 10 11 10 11 11 12 10 11 11	В	CAM BOLT	877 EM	30
E CSK SCREW M3.5 x 12mm 36 F CSK SCREW M4 x 30mm 14 G CSK SCREW M4 x 38mm 10 H JCN M6 10 I JCBC SCREW M6 x 12mm 4 J JCBC SCREW M6 x 25mm 37 K JCBC SCREW M6 x 30mm 77 L JCBC SCREW M6 x 50mm 13 M PVC NAIL 5/8"	С	WOOD DOWEL M6 x 25mm		45
F CSK SCREW M4 x 30mm 14 G CSK SCREW M4 x 38mm 10 H JCN M6 10 I JCBC SCREW M6 x 12mm 4 J JCBC SCREW M6 x 25mm 3 K JCBC SCREW M6 x 30mm 7 L JCBC SCREW M6 x 50mm 13 M PVC NAIL 5/8" 15 N METAL RUNNER TRUCK 14" 2 set O METAL RUNNER 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT 4 T KNOB HANDLE 2613 2 U STICKER 20mm 18 V ALLEN KEY 2	D	STEEL NUT M6	6	13
G CSK SCREW M4 x 38mm 10 H JCN M6 Image: Screw of the control of the contro	Е	CSK SCREW M3.5 x 12mm		36
G CSK SCREW M4 x 38mm 10 H JCN M6 Image: Screw of the control of the contro	F	CSK SCREW M4 x 30mm	Matatata	14
I JCBC SCREW M6 x 12mm 4 J JCBC SCREW M6 x 25mm 3 K JCBC SCREW M6 x 30mm 7 L JCBC SCREW M6 x 50mm 13 M PVC NAIL 5/8" 15 N METAL RUNNER TRUCK 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT 3 T KNOB HANDLE 2613 2 U STICKER 20mm 18 V ALLEN KEY 2	G	CSK SCREW M4 x 38mm	Grana	10
J JCBC SCREW M6 x 25mm 3 K JCBC SCREW M6 x 30mm 7 L JCBC SCREW M6 x 50mm 13 M PVC NAIL 5/8" 15 N METAL RUNNER TRUCK 14" 2 set O METAL RUNNER 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT 4 T KNOB HANDLE 2613 2 U STICKER 20mm 18 V ALLEN KEY 2	Н	JCN M6		10
K JCBC SCREW M6 x 30mm 7 L JCBC SCREW M6 x 50mm 13 M PVC NAIL 5/8" ∅ 15 N METAL RUNNER TRUCK 14" 2 set O METAL RUNNER 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT ∅ 4 T KNOB HANDLE 2613 ∅ 2 U STICKER 20mm ○ 18 V ALLEN KEY 2	I	JCBC SCREW M6 x 12mm	Q tto	4
L JCBC SCREW M6 x 50mm 13 M PVC NAIL 5/8" 15 N METAL RUNNER TRUCK 14" 2 set O METAL RUNNER 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT 4 T KNOB HANDLE 2613 2 U STICKER 20mm 18 V ALLEN KEY 2	J	JCBC SCREW M6 x 25mm	Outro	3
M PVC NAIL 5/8" ∅ 15 N METAL RUNNER TRUCK 14" 2 set O METAL RUNNER 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT ∅ 4 T KNOB HANDLE 2613 ∅ 2 U STICKER 20mm ○ 18 V ALLEN KEY 2	K	JCBC SCREW M6 x 30mm		7
N METAL RUNNER TRUCK 14" 2 set O METAL RUNNER 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT 4 T KNOB HANDLE 2613 2 U STICKER 20mm 18 V ALLEN KEY 2	L	JCBC SCREW M6 x 50mm	Omm	13
O METAL RUNNER 14" 2 set Q NAIL 18 R PVC L BRACKET 3 S METAL SHELF SUPPORT 4 T KNOB HANDLE 2613 □ 2 U STICKER 20mm □ 18 V ALLEN KEY 2	М	PVC NAIL 5/8"	D	15
Q NAIL ✓ 18 R PVC L BRACKET ♠ 3 S METAL SHELF SUPPORT ♠ 4 T KNOB HANDLE 2613 ♦ 2 U STICKER 20mm ○ 18 V ALLEN KEY 2	N	METAL RUNNER TRUCK 14"		2 set
R PVC L BRACKET 3 S METAL SHELF SUPPORT 4 T KNOB HANDLE 2613 © 2 U STICKER 20mm 0 18 V ALLEN KEY 2	0	METAL RUNNER 14"		2 set
S METAL SHELF SUPPORT T KNOB HANDLE 2613 U STICKER 20mm D 18 V ALLEN KEY 2	Q	NAIL		18
T KNOB HANDLE 2613 ∅ 2 U STICKER 20mm ◯ 18 V ALLEN KEY ∅ 2	R	PVC L BRACKET		3
U STICKER 20mm O 18 V ALLEN KEY 2	S	METAL SHELF SUPPORT	D	4
V ALLENKEY 2	Т	KNOB HANDLE 2613	Ø	2
	U	STICKER 20mm	0	18
W CSK SCREW M4 x 45mm 2	V	ALLEN KEY		2
	W	CSK SCREW M4 x 45mm	Gunning	2

Vendor: S000398

Carton 2 of 3:

Part	Description	Qty
Р	METAL SUPPORT 1920mm	1





** WARNING: THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.

Page 4 of 16

30 OT THE 30 В 45 С 13 D Ε 12 Q 15 Μ 2


Insert hardware part (A) and part (B) using a screwdriver (not provided). Insert hardware part (C) using a small mallet (not provided). Insert hardware part (D) using a screwdriver (not provided). Insert hardware part (M) using a small mallet (not provided). Attach hardware part (N) with screw (E) using screwdriver (not provided).





Vendor: S000398 Attach the bottom back panel (6) to the right panel (2) with screw (L) by using allen key (V) and tighten clockwise.


DO NOT use any power tools as this may damage the frame and will invalidate any claim.



3


L	Orinina	6
٧		1

Attach the back panel (3) and bottom back panel (6) to the left panel (1) and right panel (2) with screw (L) by using allen key (V) and tighten clockwise.




Fix the ladder step panel (21) and ladder bottom support panel (22) to the ladder right panel (20) by using a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Fix the ladder step panel (21) and ladder bottom support panel (22) to the left panel (1) by using a screwdriver (not provided).



L **3** 5

Vendor: S000398 Attach the front panel (4) to the left panel (1) and right panel (2) and ladder right panel (20) with screw (L) by using allen key (V) and tighten clockwise.


DO NOT use any power tools as this may damage the frame and will invalidate any claim.



7


Н	2	3
K	Ottitio	5
V		2

Insert hardware part (H) to back panel (3) by using allen key (V). Attach support panel (5) to back panel (3) with screw (K) by using allen key (V) and tighten clockwise.



 Vendor: S000398 Insert hardware part (H) to front panel (4) by using allen key (V). Attach support panel (5) to front panel (4) with screw (J) and (K) by using allen key (V) and tighten clockwise.


DO NOT use any power tools as this may damage the frame and will invalidate any claim.



9


Н	2	4
I	9	4
٧		2
Р		1

Insert hardware part (H) to left panel (1) and right panel (2) and fix hardware (P) with screw (I) by using allen key (V) and tighten clockwise.




Vendor: S000398 F | 12 Attach base panel (7) with screw (F) by using a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.



11 W Attach the cabinet center panel


Attach the cabinet center panel (11) to the cabinet bottom panel (12) with screw (W) by screwdriver (not provided).




Vendor: S000398

Fix the cabinet left panel (9) and cabinet right panel (10) to the cabinet bottom panel (12) and cabinet plinth panel (13) by using a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Fix the cabinet top panel (8) to the cabinet left panel (9) and cabinet right panel (10) and cabinet center panel (11) by using a screwdriver (not provided). **DO NOT** use any power tools as this may damage the frame and will invalidate any claim.



Vendor: S000398


| 4 | Q | | 18 | Attach cabinet back panel (23) with nail (Q) by using small mallet (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




E 12 Fix hardware (R) with screw (E) by using screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




16 S Ø 4 Fix hardware (S) and insert cabinet movable panel (14) as shown.




17 G 6 10

Fix drawer left and right panels (16) and (17) to drawer back panel (18) with screw (G) by screwdriver (not provided). Fix drawer support panel (19) to drawer back panel (18) with screw (G) by screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.



x 2sets




x 2sets


19

F	MITTUTE	2
Т	8	2

Fix drawer front panel (15) by screwdriver (not provided). Attach hardware part (T) with screw (F) using screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.






x 2sets

E 12
0 2


Vendor: S000398 Fix hardware (O) onto the drawer left panel and drawer right panel (16) and (17) using screw (E) by screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




x 2sets

21 U O 18 Cover screw hole with sticker (U) as shown.



Page 15 of 16





.Additional Information:

.For complete product information, images and dimension diagrams please visit the website www.birlea.com

.If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.

.Why don't you send us photos of your assembled furniture to info@birlea.com to be shared in our #birleahome feature on lnstagram.

Page 16 of 16