


NEVADA 3 DRAWER CHEST ASSEMBLY INSTRUCTIONS BLACK WOOD GRAIN




IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER


CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.



TOOLS REQUIRED



PARTS LIST




















Please Note:

The below parts have all been stamped with the part number to help identify them during assembly.

Part Number	Part Code	Part Description	Quantity	Carton
1	S100-102-147-DM1-01	Right Side Panel	1	1/1
2	S100-102-147-DM1-02	Left Side Panel	2	1/1
3	S100-102-147-DM1-03	Front Baseboard	2	1/1
4	S100-102-147-DM1-04	Back Baseboard	2	1/1
5	S100-102-147-DM1-05	Crossbar	1	1/1
6	S100-102-147-DM1-06	Top Panel	1	1/1
7	S100-102-147-DM1-07	Back Panel	2	1/1
8	S100-102-147-DM1-08	Drawer Side	6	1/1
9	S100-102-147-DM1-09	Drawer Back Panel	3	1/1
10	S100-102-147-DM1-10	Drawer Front	3	1/1
11	S100-102-147-DM1-11	Drawer Bottom	3	1/1
12	S100-102-147-DM1-12	Drawer Bottom Support Bar	3	1/1


FITTINGS LIST






SEC/SH/02/22/DM1

<p>A</p>  <p>Flat Head Screw Ø6,0 x 8mm (12x)</p> <p>2/+</p>	<p>B</p>  <p>Flat Head Screw Ø4,0 x 14mm (18x)</p> <p>2/+</p>	<p>C</p>  <p>Flan Head Screw Ø4,0 x 20mm (6x)</p> <p>1/+</p>	<p>D</p>  <p>Flat Head Screw Ø4,0 x 45mm (12x)</p> <p>2/+</p>
<p>E</p>  <p>Flan Head Screw Ø3,5 x 12mm (6x)</p> <p>1/+</p>	<p>F</p>  <p>Dowel Ø6,0 x 30mm (44x)</p> <p>2/+</p>	<p>G</p>  <p>Nail 10 x 10 (60x)</p> <p>5/+</p>	<p>H</p>  <p>Cam Nut Ø12mm (10x)</p> <p>2/+</p>
<p>I</p>  <p>Flat Head Screw Ø3,5 x 25mm (3x)</p> <p>1/+</p>	<p>J</p>  <p>Washer (4x)</p> <p>1/+</p>	<p>K</p>  <p>Plastic Foot (6x)</p> <p>1/+</p>	<p>L</p>  <p>Flan Head Screw Ø3,5 x 30mm (2x)</p> <p>1/+</p>
<p>M</p>  <p>Cam Bolt (10x)</p> <p>2/+</p>	<p>N</p>  <p>Hole Plugs (18x)</p> <p>2/+</p>	<p>O</p>  <p>GLUE</p> <p>Glue (2x)</p>	<p>P</p>  <p>Drawer Runners (3x)</p>
<p>Q</p>  <p>Back Panel Strip (1x)</p>	<p>R</p>  <p>Strap (2x)</p>	<p>S</p>  <p>Handle (3x)</p>	


TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE





    

CORRECT **WRONG**



Cam bolt head needs to be in centre

CAMBOLT
Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)





STEP 1

PARTS REQUIRED

2 - LEFT SIDE PANEL x1

HARDWARE REQUIRED



F  02
Ø6 x 30

G  02
10 x 10


K  02

O  01
GLUE

TOOLS REQUIRED



Detail 1




Detail 4


STEP 2

PARTS REQUIRED

1 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED




F  02
Ø6 x 30

G  02
10 x 10


K  02

O  01
GLUE

TOOLS REQUIRED



Detail 1



Detail 4


STEP 3

PARTS REQUIRED





2 - LEFT SIDE PANEL x1

HARDWARE REQUIRED

A  06
Ø6.0 x 8mm

P  03
LEFT

TOOLS REQUIRED




STEP 4

PARTS REQUIRED





1 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED

A  06
Ø6.0 x 8mm

P  03
RIGHT

TOOLS REQUIRED







STEP 5





PARTS REQUIRED

3 - FRONT BASEBOARD	x1
4 - BACK BASEBOARD	x1
5 - CROSSBAR	x1

HARDWARE REQUIRED

F		10
G		02
K		02
O		01

TOOLS REQUIRED





STEP 6






PARTS REQUIRED

1 - RIGHT SIDE PANEL	x1
3 - FRONT BASEBOARD	x1
4 - BACK BASEBOARD	x1
5 - CROSSBAR	x1

HARDWARE REQUIRED

D		03
O		01


TOOLS REQUIRED




STEP 7

PARTS REQUIRED

2 - LEFT SIDE PANEL x1





HARDWARE REQUIRED


D  Ø4,0 x 45mm 03

O  GLUE 01


TOOLS REQUIRED



Detail 1



Detail 6




Detail 13

STEP 8




PARTS REQUIRED

6 - TOP PANEL x1


HARDWARE REQUIRED

M  04

TOOLS REQUIRED




Detail 2




STEP 9

PARTS REQUIRED

6 - TOP PANEL x1





HARDWARE REQUIRED


H  04

K  01


TOOLS REQUIRED



Detail 1



Detail 7




Cam bolt head needs to be in centre

STEP 10


PARTS REQUIRED

7 - BACK PANEL x2






HARDWARE REQUIRED

E  06
Ø3,5 x 12mm



G  20
10 x 10

Q  01



TOOLS REQUIRED




Detail 8



* For your future reference
Order Number should be here



Detail 16





Detail 8

STEP 11



PARTS REQUIRED

- 8 - DRAWER SIDE x6
- 9 - DRAWER BACK PANEL x3
- 12 - DRAWER BOTTOM SUPPORT BAR X3

HARDWARE REQUIRED

- F  30
Ø6,0 x 30mm
- O  01
GLUE

TOOLS REQUIRED




STEP 12




PARTS REQUIRED

- 10 -DRAWER FRONT x3

HARDWARE REQUIRED

- M  06

TOOLS REQUIRED




STEP 13

PARTS REQUIRED



8 - DRAWER SIDE x6

9 - DRAWER BACK PANEL x3

HARDWARE REQUIRED

D  06
Ø4,0 x 45mm


TOOLS REQUIRED



STEP 14

PARTS REQUIRED


10 - DRAWER FRONT x3



HARDWARE REQUIRED


O  01
GLUE

TOOLS REQUIRED




STEP 15





PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




STEP 16

PARTS REQUIRED






11 - DRAWER BOTTOM x3



HARDWARE REQUIRED




TOOLS REQUIRED




STEP 17

PARTS REQUIRED




12 - DRAWER BOTTOM SUPPORT BAR X3



HARDWARE REQUIRED

G  18
10 x 10

TOOLS REQUIRED




Detail 1


Detail 10


STEP 18


PARTS REQUIRED



HARDWARE REQUIRED



B  12
Ø4,0 x 14mm

I  03
Ø3,5 x 25mm

P  03
LEFT



P  03
RIGHT

TOOLS REQUIRED



FIRST HOLE

LAST SECOND HOLE




LAST SECOND HOLE



FIRST HOLE

STEP 19




PARTS REQUIRED



HARDWARE REQUIRED





TOOLS REQUIRED



Detail 11

STEP 20



PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




Detail 12

TIP
If desired, after assembly use an alcohol cleaner to erase the number printed on the parts.




STEP 21




PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED



WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

