




# VERMONT 3 DOOR WARDROBE ASSEMBLY INSTRUCTIONS WHITE/GREY




**IMPORTANT  
FOR DOMESTIC USE ONLY  
PLEASE READ BEFORE YOU CONTINUE FURTHER**

## CARE AND MAINTENANCE

- After unpacking this product please keep the original packaging in case it needs to be returned for any reason.
- Please ensure all fittings and parts are present before commencing with assembly.
  - Never drag or push products as this could cause damage to the joints making it inferior.
  - We strongly recommend that you keep children away from your work area.
  - We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
  - Assemble this product as close to its final position as possible.
  - Do not place this product next to a radiator or in direct sunlight.
  - Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
  - Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
  - Make sure any spillage is wiped off immediately.
  - Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
  - For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
  - From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
  - Do not place on a wet or damp floor as staining may occur to your floor.



**TOOLS REQUIRED**






























**PARTS LIST**



**Please Note:**  
The below parts have all been stamped with the part number to help identify them during assembly.

Part Number	Part Code	Part Description	Quantity	Carton
1	S100-101-093-DV1-01	Front Left Upright	1	1/3
2	S100-101-093-DV1-02	Left Side Panel	1	1/3
3	S100-101-093-DV1-03	Left Rear Upright	1	1/3
4	S100-101-093-DV1-04	Shelf Large	1	3/3
5	S100-101-093-DV1-05	Shelf	3	2/3
6	S100-101-093-DV1-06	Base Panel	1	3/3
7	S100-101-093-DV1-07	Crossbeam	1	3/3
8	S100-101-093-DV1-08	Central Foot	1	3/3
9	S100-101-093-DV1-09	Division Panel	1	1/3
10	S100-101-093-DV1-10	Right Front Upright	1	1/3
11	S100-101-093-DV1-11	Right Side Panel	1	1/3
12	S100-101-093-DV1-12	Rear Right Upright	1	1/3
13	S100-101-093-DV1-13	Top Panel	1	3/3
14	S100-101-093-DV1-14	Back Panel	2	2/3
15	S100-101-093-DV1-15	Hanging Rail	1	3/3
16	S100-101-093-DV1-16	Door	3	2/3
17	S100-101-093-DV1-17	Back Panel	1	2/3

### FITTINGS LIST


<b>A</b>  Glue (2x)	<b>B</b>  2/+ Dowel Ø6,0 x 30mm (38x)	<b>C</b>  1/+ Cam Nut (30x)	<b>D</b>  Handle(3x)
<b>E</b>  CH PHS ZP 3/16X5/8 (3x)	<b>F</b>  Hinge (9x)		<b>G</b>  6/+ Nail 10 x 10 (69x)
<b>H</b>  2/+ Flat Head Screw Ø3,5 x 16mm (36x)	<b>I</b>  2/+ Hole Plugs (56x)	<b>J</b>  2/+ Cam Bolt (26x)	<b>K</b>  Hanging Rail (2x)
<b>L</b>  2/+ Flat Head Screw Ø3,5 x 10mm (24x)	<b>M</b>  1/+ Metalic Support (2x)	<b>N</b>  Roller Clasp (6x)	
<b>O</b>  Roller Clasp (6x)	<b>P</b>  1727 mm Back Panel Strip (1x)	<b>R</b>  Ø3,5x25 <b>01</b>  Washer <b>02</b>  Anti-tip strap <b>01</b> (2x)	
<b>Q</b>  2/+ Flat Head Screw Ø3,5 x 25mm (20x)			
<b>S</b>  Allen Key (1x)	<b>T</b>  1/+ Structural screw (1x)	<b>U</b>  1/+ Dowel Ø6,0 x 50mm (2x)	<b>V</b>  Double Cam Bolt (2x)
<b>W</b>  1/+ Flat Head Screw Ø3,5 x 10mm (8x)	<b>X</b>  2/+ Back Panel Bracket (12x)	<b>Y</b>  1/+ Flat Head Screw Ø3,0 x 12mm (9x)	

### TIPS FOR FITTINGS CAM-LOCKS



### CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)






# STEP 1






## PARTS REQUIRED

4 - SHELF LARGE	x1
5 - SHELF	x3

## HARDWARE REQUIRED

A		01
B		12
U		02

## TOOLS REQUIRED



Detail 1



Detail 17

# STEP 2






## PARTS REQUIRED

6 - BASE PANEL	x1
7 - CROSSBEAM	x1
9 - DIVISION PANEL	x1

## HARDWARE REQUIRED

A		01
B		10

## TOOLS REQUIRED



Detail 1

# STEP 3




## PARTS REQUIRED

06-BASE PANEL x1

## HARDWARE REQUIRED

M		02
W		02
L		06
O		03
J		02

## TOOLS REQUIRED



# STEP 4

## PARTS REQUIRED




09-DIVISION PANEL x1

08-CENTRAL FOOT x1

## HARDWARE REQUIRED

J		04
K		01
W		02
T		01

## TOOLS REQUIRED



# STEP 5

## PARTS REQUIRED

13 - TOP PANEL x1




## HARDWARE REQUIRED

J  06

L  06  
Ø3,5 x 10mm

O  03

## TOOLS REQUIRED



# STEP 6

## PARTS REQUIRED

1 - FRONT LEFT UPRIGHT x1


3 - LEFT REAR UPRIGHT x1

10 - RIGHT FRONT UPRIGHT x1




12 - REAR RIGHT UPRIGHT x1

## HARDWARE REQUIRED

A  01  
Glue

B  12  
Ø6,0 x 30mm

## TOOLS REQUIRED





# STEP 7



**PARTS REQUIRED**

- 1 - FRONT LEFT UPRIGHT x1
- 2 - LEFT SIDE PANEL x1

**HARDWARE REQUIRED**

- Q  05  
Ø3,5 x 25mm
- I  08

**TOOLS REQUIRED**







# STEP 8



**PARTS REQUIRED**

- 2 - LEFT SIDE PANEL x1
- 3 - LEFT REAR UPRIGHT x1

**HARDWARE REQUIRED**

- A  01
- B  02  
Ø6,0 x 30mm
- I  08
- Q  05  
Ø3,5 x 25mm

**TOOLS REQUIRED**



# STEP 9



## PARTS REQUIRED

2 - LEFT SIDE PANEL x1

## HARDWARE REQUIRED

J  09

## TOOLS REQUIRED




# STEP 10

## PARTS REQUIRED


10 - REAR RIGHT UPRIGHT x1

11 - RIGHT SIDE PANEL x1



## HARDWARE REQUIRED

A  01

I  08

Q  05  
Ø3,5 x 25mm

## TOOLS REQUIRED





# STEP 11


## PARTS REQUIRED

11 - RIGHT SIDE PANEL x1


12 - REAR RIGHT UPRIGHT x1

## HARDWARE REQUIRED




A  01

B  02  
Ø6,0 x 30mm


I  08

Q  05  
Ø3,5 x 25mm


## TOOLS REQUIRED




Detail 1



Detail 5



Detail 15




# STEP 12

## PARTS REQUIRED

11 - RIGHT SIDE PANEL x1




## HARDWARE REQUIRED

K  01


W  02  
Ø3,5 x 10mm

J  05


## TOOLS REQUIRED




Detail 6



Detail 6



Detail 4



# STEP 13

## PARTS REQUIRED

6 - BASE PANEL x1

9 - DIVISION PANEL x1




## HARDWARE REQUIRED

A  01


C  02

I  02


## TOOLS REQUIRED



Detail 16



Detail 7




Cam bolt head needs to be in centre


# STEP 14

## PARTS REQUIRED

5 - SHELF x3




## HARDWARE REQUIRED




A  01

C  06


I  06

V  02


## TOOLS REQUIRED




Detail 16



Detail 7



Cam bolt head needs to be in centre




Detail 20

# STEP 15

## PARTS REQUIRED



2 - LEFT SIDE PANEL x1



## HARDWARE REQUIRED

A		01
C		08
I		06

## TOOLS REQUIRED




# STEP 16

## PARTS REQUIRED

4 - SHELF LARGE x1



7 - CROSSBEAM x1



## HARDWARE REQUIRED

A		01
C		03
I		02


## TOOLS REQUIRED






# STEP 17

## PARTS REQUIRED







11- LEFT SIDE PANEL x1



## HARDWARE REQUIRED

- A  01
- C  05
- I  02


## TOOLS REQUIRED







# STEP 18

## PARTS REQUIRED







13 - TOP PANEL x1



## HARDWARE REQUIRED

- A  01
- C  06
- I  06
- W  02  
Ø3,5 x 10mm

## TOOLS REQUIRED




# STEP 19


## PARTS REQUIRED


14 - BACK PANEL x2

17 - BACK PANEL x1






## HARDWARE REQUIRED

G  60

P  01


X  12

## TOOLS REQUIRED




# STEP 20



## PARTS REQUIRED



## HARDWARE REQUIRED

G  09


## TOOLS REQUIRED



# STEP 21



## PARTS REQUIRED

15 - HANGING RAIL x1



## HARDWARE REQUIRED

## TOOLS REQUIRED







Detail 10

# STEP 22


## PARTS REQUIRED

16 - DOOR x3

## HARDWARE REQUIRED



- F  09
- H  18  
Ø3,5 x 16mm
- L  12  
Ø3,5 x 10mm
- N  06

## TOOLS REQUIRED





PLEASE NOTE  
PRE-DRILLED  
HOLES.

**3X**



Detail 12




Detail 13

# STEP 23


## PARTS REQUIRED


16 - DOOR x2





## HARDWARE REQUIRED

D  02

E  02

H  18  
Ø3.5 x 16mm


## TOOLS REQUIRED



# STEP 24

## PARTS REQUIRED


16 - DOOR x1





## HARDWARE REQUIRED

D  01

E  01


Y  09  
Ø3.0 x 12mm

## TOOLS REQUIRED



# STEP 25


**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**



## WARNING

**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

