




BLACK WOOD GRAIN LISBON BLANKET BOX ASSEMBLY INSTRUCTIONS



FOR DOMESTIC USE ONLY IMPORTANT

PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE.
DO NOT OVERTIGHTEN FIXING.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET)
DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.










THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




PART LIST

<u>Part Number</u>	<u>Part Code</u>	<u>Part Description</u>	<u>Quantity</u>	<u>Carton</u>
1	S100-104-004-EU1-01	Bottom Panel	1	1/1
2	S100-104-004-EU1-02	Front Panel	1	1/1
3	S100-104-004-EU1-03	Back Panel	1	1/1
4	S100-104-004-EU1-04	Left Side Panel	1	1/1
5	S100-104-004-EU1-05	Right Side Panel	1	1/1
6	S100-104-004-EU1-06	Cushion	1	1/1


HARDWARE LIST

A		DOWEL 6 X 30MM	20 PCS
B		BOLT M6 X 50MM	8 PCS
C		SCREW M3.5 X 16MM	20 PCS
D		L SHAPE HINGE	2 PCS
E		HINGE (L&R)	1 SET
F		ALLEN KEY	1 PC
G		PLASTIC FOOT	4 PCS
H		CAM BOLT+CAM NUT	8 SETS
I		BOLT M7X 60MM	4 PCS



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.



STEP 1 - PUSH CAM BOLT INTO INSERT

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. (MAKE SURE THE ARROW OF THE CAM LOCK IS POINTING TOWARD ON THE EDGE OF THE PANEL.)

STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSES OVER THE BOLT.

STEP 1

PARTS REQUIRED


1 - BOTTOM PANEL x1

HARDWARE REQUIRED

A  12

H  08

TOOLS REQUIRED



STEP 2

PARTS REQUIRED


2 - FRONT PANEL x1

HARDWARE REQUIRED

A  04

H  04

TOOLS REQUIRED



STEP 3

PARTS REQUIRED


3 - BACK PANEL x1

HARDWARE REQUIRED

A  04

H  04

TOOLS REQUIRED




STEP 4

PARTS REQUIRED

6 - CUSHION x1



HARDWARE REQUIRED

C  08

D  02

E  02

TOOLS REQUIRED





STEP 5

PARTS REQUIRED

1 - BOTTOM PANEL	x1
2 - FRONT PANEL	x1
3 - BACK PANEL	x1


TOOLS REQUIRED



STEP 6

PARTS REQUIRED


4 - LEFT SIDE PANEL	x1
5 - RIGHT SIDE PANEL	x1



HARDWARE REQUIRED


B		04
I		02

TOOLS REQUIRED





STEP 7

PARTS REQUIRED




HARDWARE REQUIRED



B  04

C  04

G  04

I  02


TOOLS REQUIRED




STEP 8

PARTS REQUIRED



6 - CUSHION x1







HARDWARE REQUIRED

C  04

TOOLS REQUIRED



STEP 9PARTS REQUIREDHARDWARE REQUIREDC  04TOOLS REQUIRED**STEP 10**