



ASSEMBLY INSTRUCTIONS
FRANCIS STORAGE BED 3' FT

IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR WOODEN OTTOMAN 3' BED FRAME.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.


HEALTH & SAFETY:

- DO NOT jump on this bed frame.
- DO NOT use this bed frame if any parts are missing, damaged or worn.
- DO NOT use this bed frame unless all fixings are secured.
- Please keep small parts out of reach of children.
- Always use on a level, even surface.
















WARNING: If this bed is placed on a non-carpeted floor you must place some protection under all legs to stop the bed frame from moving. If this is not adhered to there is no guarantee if the bed frame collapses.

CARE & MAINTENANCE:



















- Assemble in the room of use.
- Periodically check all screws & fixings to ensure they are secure.
- DO NOT push the bed frame as this will damage the legs.
- Always lift the bed with two people to reposition.
- Keep any sharp objects away from the frame.



Parts List

Part	Description	Box	Qty
1	Headboard Frame 	1/6	1
2	Left Wooden Post 	1/6	1
3	Right Wooden Post 	1/6	1
4	Footboard Frame 	2/6	1
5	Left Side Rail 	4/6	1
6	Right Side Rail 	4/6	1
7	Back Storage Panel 	5/6	1
8	Center Storage Panel 	5/6	1
9	Base Panel (A) With 4 Holes 	3/6	1
10	Base Panel (B) With 2 Holes 	3/6	1
11	Wood Slats 	4/6	14
12	Left Hydraulic Base Support with Stopper 	6/6	1
13	Right Hydraulic Base Support 	6/6	1
14	Hydraulic Pump 	6/6	2
15	Bed Base 	3/6	1


Hardware List

Part	Description		Box	Qty
A	JCBC BOLT M8 x 25MM		4/6	16
B	JCBC BOLT M8 x 15MM		4/6	8
C	JCBC BOLT M8 x 20MM		4/6	8
D	BASE HANDLE		4/6	3
E	JCBC BOLT M6 x 40MM		4/6	6
F	M8 x 45MM RH BOLT c/w HEX NUT, SPRING & FLAT WASHER		4/6	6
G	SINGLE END PLASTIC CAP		4/6	28
H	SUPPORT LEG		3/6	2
I	JCBC BOLT M8 x 40MM (assembled)		4/6	2
J	ML-CB (METAL CORNER SUPPORT)		4/6	2
K	JCBC BOLT M6 x 90mm + BARREL NUT		4/6	4
L	WOOD DOWEL		4/6	12
M	WOOD BUTTON		4/6	4
N	MINI FIX		4/6	8
O	ALLEN KEY - M6		4/6	1
P	ALLEN KEY - M8		4/6	1
Q	M12.8 SPANAR		4/6	1
R	M14 SPANAR		4/6	1

** You will also need a screwdriver and small mallet (not provided).


Step 1: Attach the headboard frame (1) and back storage panel (7) to the left wooden post (2) and right wooden post (3). Secure the headboard frame using hardware parts K, L and M, then secure the back storage panel with hardware parts L and N.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Step 2: Join together the left side rail (5) and right side rail (6) with the centre storage panels (8) using hardware parts L and N.


DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Step 3: Attach the headboard frame (1) and footboard (4) using hardware part A.
DO NOT use any power tools as this may damage the frame and will invalidate any claim.



Step 4: Attach hardware part B using hardware parts J.
DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Step 5: Attach the hydraulic pumps (14) to the left hydraulic base support (12) and right hydraulic base support (13) as shown in Fig 5.1.



5.1 Hydraulic Pump right installation.


- Next, ensure your hydraulic opening side. Locate your hydraulic base support through the JCBC holes L1, L2, L3 & L4 or R1, R2, R3 & R4 at headboard and footboard as shown in Fig 5.2.

OPTION 1 (LEFT OPENING)





5.2 Hydraulic Pump Base Support installation for **OPTION 1**

OPTION 2 (RIGHT OPENING)




5.2 Hydraulic Base Support installation for **OPTION 2**


- Make sure fix hardware C at round end hole first (L1/R1) as shown in Fig 5.3 and do not tighten yet. Finally, fix all hardware C and tighten all bolts as shown in Fig 5.4. **DO NOT** use any power tools as this may damage the frame and will invalidate any claim.




Step 6: Insert the large base panels (9) and small base panel (10).
DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Step 7: Attach hardware parts K using hardware part L to the bed base (15) as shown.
DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Step 8: Insert the slats (11) to hardware parts G then press into the base making sure they are secure.
DO NOT use any power tools as this may damage the frame and will invalidate any claim.



Step 9: Attach the bed base to the hydraulic frames using hardware part F. Fix the bolts starting from area 1 and finishing in area 3 – do not fully tighten the bolts yet.
DO NOT use any power tools as this may damage the frame and will invalidate any claim.





Step 10: Adjust the bed base making sure that the distance to the footboard is approximately 10 – 15 mm.
Tighten all bolts and screws now.
DO NOT use any power tools as this may damage the frame and will invalidate any claim.





THE BED HAS BEEN FULLY ASSEMBLED

Option 1 (LEFT OPENING)



Option 2 (RIGHT OPENING)



" IMPORTANT NOTE "

WHEN THE BED IS BUILT AND THE MATTRESS FRAME IS AT 45 DEGREE
PLEASE PLACE THE MATTRESS ON THE BED.

PLEASE NOTE THAT THE WEIGHT OF THE MATTRESS IS REQUIRED TO
HELP CLOSE THE BED.

TO LOWER THE SLEEPING PLATFORM STAND AT THE SIDE RAIL OF THE
BED AND PUSH SHARPLY
DOWNWARDS USING BOTH HANDS.

