


MIDSLEEPER - Quad Unit

ASSEMBLY INSTRUCTION



SAFETY ADVICE

Please take the time to carefully read through the whole of these instruction before you commence.

Keep these instruction for future reference.

Unpack,inspect and check of all of the contents.

Please dispose of all packing safely.

Small components parts could choke a child is swallowed.

We strongly recommend that you keep children well away from the work area.

It would be sensible to lay a sheet or blanket on the floor where you intend to work to avoid


Scratching this product and protect your floor.

This bed is heavy. Always lift this bed with two people.

Assemble the product as close to its intended final position in the room as possible.

Keep any sharp object away from the bed frame.

HANDY HINT: If you keep the hardware in bowl during assembly you will be less likely to lose them



PART LIST

Model : MIDSLEEPER - Quad Unit

Carton 5 of 5


No.	Part Name	Pcs
G	Side Panel Left	1
H	Side Panel Right	1
J	Center Panel Upper	1
JL	Center Panel Lower	1
K	Shelf Fix Panel	1
L	Front Leg	1
M	Bottom Panel	1
N	Top Panel	1
P	Back Panel	2

FITTING LIST


Hardware



1 x 22
Camlock



3 x 18
Camlock Bolt



6 x 2
Minifit Bolt




20 x 19
M8 x 25mm PVC Dowel



22 x 2
M8 x 50mm PVC Dowel




29 x 6
M3 x 19mm screw





53 x 6
Stub 192


Parts



Step 1

DO NOT use any power tools as this may damage the panel part and will invalidate any claim.

1		x22
20		x19




Step 2

DO NOT use any power tools as this may damage the panel part and will invalidate any claim.

3



x18



Step 3

DO NOT use any power tools as this may damage the panel part and will invalidate any claim.

6






x2

22





x2





ATTENTION !

- Lock 1 as shown below.
- Tighten 1 at step 4.





Step 4 DO NOT use any power tools as this may damage the panel part and will invalidate any claim.



WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CAMLOCK OR DRAWER CAMLOCK.
TURN CLOCKWISE UNTIL SECURE



Step 5 DO NOT use any power tools as this may damage the panel part and will invalidate any claim.



WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CAMLOCK OR DRAWER CAMLOCK.
TURN CLOCKWISE UNTIL SECURE

Step 6


DO NOT use any power tools as this may damage the panel part and will invalidate any claim.



WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CAMLOCK OR DRAWER CAMLOCK.
TURN CLOCKWISE UNTIL SECURE



Step 7

DO NOT use any power tools as this may damage the panel part and will invalidate any claim.



Step 8


DO NOT use any power tools as this may damage the panel part and will invalidate any claim.




WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CAMLOCK OR DRAWER CAMLOCK.
TURN CLOCKWISE UNTIL SECURE

Step 9

DO NOT use any power tools as this may damage the panel part and will invalidate any claim.




Step 10 DO NOT use any power tools as this may damage the panel part and will invalidate any claim.



Step 11 DO NOT use any power tools as this may damage the panel part and will invalidate any claim.

29		x6
53		x6



COMPLETED

DO NOT use any power tools as this may damage the panel part and will invalidate any claim.

